

## Firmware Upgrade – GV-DVR1042

Copy the new FW in to the root directory of your USB Memory.

Plug your USB Memory in to the front USB port.

1. Press "MENU"
2. Select "SYSTEM"



3. Select "SYSTEM MANAGEMENT"



**4. Select "F/W UPDATE" and press "ENTER"**



**5. Select the new version from the list and press "START"**

**6. When the DVR asks you to reboot, select "OK" and press "ENTER"**

**After update is completed, you will have a USB mouse control.**

